

Variations in Computed Neutron Multiplication of Deuterium Moderated Highly Enriched Uranium Systems

R. G. Taylor and D. F. Hollenbach

American Nuclear Society 2013 Annual Meeting Wednesday, June 19, 2013

Data Analysis in Nuclear Criticality Safety - II

spectratechinc.com

Methodology and Observations

- Performing comprehensive, general validation of SCALE6.1/KENO V.a
 - v7-238 (ENDF/B-VII) cross sections
 - Execute each case specifying $\sigma = 0.0001$
- Noticed ~1% or more difference between v5-238 (ENDF/B-V) and v7-238 (ENDF/B-VII) cross sections for heavy water moderated and reflected high ²³⁵U enrichment systems



Reference Evaluations

- International Handbook of Evaluated Criticality Safety Benchmark Experiments
 - HEU-SOL-THERM-004:
 - Reflected Uranyl-Fluoride Solutions in Heavy Water
 - HEU-SOL-THERM-020:
 - Unreflected Cylinders of Uranyl-Fluoride Solutions in Heavy Water
- Both evaluations remark upon differences in results between ENDF/B-V and ENDF/B-VI cross sections
- Various reports of issues with and changes to ENDF/B cross sections for deuterium



Piqued Curiosity

- Explore using various codes
 - SCALE6.1/KENO V.a
 - The code being validated
 - Various ENDF/B cross section sets available
 - MCNP5
 - Used for various previous works
 - Various ENDF/B cross section sets available
 - $S(\alpha, \beta)$ scattering available
 - Easy to select/mix cross sections



HEU-SOL-THERM-004



concentration	moderation				
(g ²³⁵ U/L)	(²H/²³⁵U)				
679	34.2				
443	53.7				
302	81.2				
185	135.3				
104	243				
60	431				



HEU-SOL-THERM-020



concentration	moderation			
(g ²³⁵ U/L)	(² H/ ²³⁵ U)			
109.4	230			
61	419			
30.1	856			
12.4	2081			



Concentration/Moderation Span



Spectra

7

Benchmark Particulars

	HEU-SOL-THERM-004						HEU-SOL-THERM-020				
case no.	1	2	3	4	5	6	1	2	3	4	5
concentration (g ²³⁵ U/L)	679	443	302	185	104	60	109.4	61	30.1	30.1	12.4
² H/ ²³⁵ U atom ratio	34.2	53.7	81.2	135.3	243	431	230	419	856	856	2081
benchmark k _{eff}	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	0.9966	0.9956	0.9957	0.9955	0.9959
benchmark uncertainty	0.0033	0.0036	0.0039	0.0046	0.0052	0.0059	0.0058	0.0047	0.0040	0.0039	0.0039



Correspondences

SCALE6.1	MCNP5
V5-238	.50c B-V.0 (² H & ²³⁵ U)
ENDF/B-V	.01t endf5
V6-238	.60c B-VI.0 (² H), B-VI.2 (²³⁵ U)
ENDF/B-VI release 8	.60t endf6.3
V7-238	.70c B-VII.0 (² H & ²³⁵ U)
ENDF/B-VII release 0	.10t endf7.0







Spectra Tech

10













Spectra

lech ...





Spectra Tech





Spectra Tech ...

















Spectra Tech ...





Spectra Tech ...



















ENDF/B-V and -VII



ENDF/B-V with ENDF/B-VII ²³⁵U



ENDF/B-V with ENDF/B-VII ²H



CONCLUSIONS

- There is a bias as a function of ²³⁵U concentration ranging from about 3% high at lower concentrations to about 2% low at higher concentrations depending on the cross section set.
- In the 60 to 100 g ²³⁵U/L range where the experimental systems overlap, results are indicated to diverge as concentration decreases - this may be related to presence/absence of a heavy water reflector.
- There are differences in results using ENDF/B-V cross sections compared to results using ENDF/B-VII cross sections and the differences become more pronounced as ²³⁵U concentration increases.
- Changes in the ²H cross sections are indicated to account for essentially all the difference in results between the ENDF/B-V and ENDF/B-VII cross sections.
- If HEU-SOL-THERM-004 systems are used in a general validation using ENDF/B-VII cross sections then expect a negative bias of about 2%.





QUESTIONS

COMMENTS

OBSERVATIONS ?

